

TEST REPORT

APPLICANT : CSP INC
ADDRESS : 8248 W. ORANGE DR GLENDALE, AZ 85303 USA
SAMPLE DESCRIPTION : FAMILY CERAMIC MUG-MDGG
STYLE / ITEM NO. : K5-620
BUYER : KIDS' KORNER
AGE REQUESTED ON APPLICATION FORM : 3+
SAMPLE RECEIVED DATE : MAY 17, 2016
TEST PERIOD : MAY 18, 2016 TO MAY 23, 2016
RESULT SUMMARY :

TEST REQUESTED	RESULT
- US FDA CPG Sec. 7117.07 Pottery (Ceramics); Import and Domestic – Lead Contamination.	PASS
- US FDA CPG Sec. 7117.06 Pottery (Ceramics); Import and Domestic – Cadmium Contamination.	PASS

*****FOR FURTHER DETAILS, PLEASE REFER TO THE FOLLOWING PAGE(S)*****

SIGNED FOR AND ON BEHALF OF
EUROFINS TESTING TECHNOLOGY (SHENZHEN) CO. LTD.



Harry Chen
Assistant Lab Manager



Coco Luo
Assistant Lab Manager



This test report is valid for the tested samples only. Without permission of the test center this test report is not permitted to be duplicated in extracts. This test report does not entitle to carry any safety mark on this or similar products.

Test Result:
US FDA CPG Sec. 7117.07 Pottery (Ceramics); Import and Domestic – Lead Contamination

Test method : AOAC methods 973.82

Test Sample			Inner of mug						Detection limit
Parameter	Category ^(^)	Unit	Test result						
			1	2	3	4	5	6	
Leachable of Lead content (Pb)	3	µg/mL	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	0.1

Remark:

(^) The permissible limit of leachable lead content is as follow:

No.	Category	Permissible Limit of Lead extracted
1	Flatware	3.0 µg/mL
2	Small hollowware other than cups and mugs	2.0 µg/mL
3	Cups and mugs	0.5 µg/mL
4	Large hollowware other than pitchers	1.0 µg/mL
5	Pitchers	0.5 µg/mL

US FDA CPG Sec. 7117.06 Pottery (Ceramics); Import and Domestic – Cadmium Contamination

Test method : AOAC methods 973.82

Test Sample			Inner of mug						Detection limit
Parameter	Category ^(^)	Unit	Test result						
			1	2	3	4	5	6	
Leachable of Cadmium content (Cd)	2	µg/mL	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	0.01

Remark:

(^) The permissible limit of leachable cadmium content is as follow:

No.	Category	Permissible Limit of Cadmium extracted
1	Flatware	0.5 µg/mL
2	Small hollowware	0.5 µg/mL
3	Large hollowware	0.25 µg/mL

 Note: - µg/mL = microgram per milliliter
 - N.D. = Not Detected

Other Information / Remark:

N/A

TO BE CONTINUED

Eurofins Testing Technology (Shenzhen) Co. Ltd.

4/F, Building# 3, Runheng Dingfeng Industrial Park, No.1 Liuxian 3rd Road, Bao'an District, Shenzhen, P.R. China

 Tel.: +86 755 8358 5700 • Fax: +86 755 8358 5701 • Email: info.hk@eurofins.com • Website: www.eurofins.com / www.pt.eurofins.com



END OF THE REPORT